

## Buzz-off! To annoying insects

Magic Seal Magnetic Insect Screens are flexible and adhere magnetically to the inside of the window frame. Perfect for most windows including Awning, Double Hung and Casement styles. Attractive and easily removed!



Our Magnetic Double Glazing for existing windows will reduce your winter heat loss and eliminate annoying condensation.

will reduce your winter heat loss and eliminate annoying condensation.



Ultimate Insect Screens Pty Ltd  
Exclusive Sydney Distributor

1300 55 36 34

www.idealscreens.com.au



## Enduro shield protective coating

Enduro Shield from Origen Australia (Sydney) is a permanent protective coating for ceramic and porcelain surfaces, grout, and all glass surfaces such as shower screens, mirrors, windows, splash-backs, glass pool fencing. Simple to apply, the invisible coating repels water, soap scum and grime; and it reduces the need to clean by up to 90%. An occasional wipe over will ensure no more scrubbing is required. It helps to promote a germ free environment and keeps glass, tile and grout surfaces looking new.



# MASCOT

## STEEL & TOOLS

261 COWARD ST, MASCOT  
**9317 5000**

95 JEDDA RD, PRESTONS  
**9826 9088**

WORKING WITH STEEL MADE EASY

www.mascotsteel.com.au



Dr Kagi PhD.

## University Stops Rising Damp

Do it Yourself the Easy Way from just \$18/Metre!

Developed by Dr Kagi, the Tech-Dry® DIY KIT means you need only a masonry drill to stop rising damp permanently.

### FREE UNIVERSITY BOOKLET

"How to Simply Identify a Damp House"

For your FREE copy call

(02) 9482 3360 - Mob 0403 383 656

- As seen on Ch 7 & Ch 9 home shows
- No structural damage
- Proven successful in over 20,000 installations for over 20 years Australia-wide
- Free advice line gives you all the technical support you need
- 100% MONEY BACK GUARANTEE

FOR FRIENDLY EXPERT ADVICE CALL

AUSTRALIAN UNIVERSITY DEVELOPED & PROVEN  
SYDNEY: 02 9482 3360  
[www.techdry.net](http://www.techdry.net)

## Installing a damp-proof course



1. Starting outside, locate the original damp-proof course at or just below floor bearer level, near the level of the under-floor vents. Install the damp-proof course at the same level as the existing one.



2. Drill a series of 10mm diameter holes at an angle of 20° to 30° to the horizontal at 125mm spacings along the wall - that is, two holes per brick. Drill 85 to 90mm deep. Mark the correct depth on the drill bit. Do not penetrate right through the brick.



3. Push the clear plastic sleeve hard onto the tube nozzle to increase its diameter slightly and insert it into a hole. Give it a twist so it seals well.



4. Cut two slits in the end of the tube to control the feed of fluid. Slip an "O" ring on the threaded section of the tube and screw it to the nozzle in the wall. Prepare 30 tubes at a time.



5. Squirt the chemical damp-proof fluid into each tube at a rate of 1.5 to 2 litres per metre of single thickness wall. The fluid soaks in over 15 to 120 minutes, depending on the porosity of the brick. If the fluid runs straight out, the hole has intercepted a crack and you will need to drill a new hole.

TRADE ENQUIRIES WELCOME